




Jazz UltraTab C855 Camera Replacement

This guide will show you how to replace a broken camera in your Jazz UltraTab C855 tablet.

Written By: Kyle Haas



INTRODUCTION

Don't dump your device simply because the camera isn't working! This guide will help you easily replace the faulty camera on your tablet.



TOOLS:


- [Phillips #000 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Back Cover




- Remove the 4 exterior screws using a [Phillips #000 Screwdriver](#).

Step 2



- Pry the back case off using the blue [Plastic Opening Tools](#). Work one along the seem until you can get your fingers under to pull it apart.

Step 3 — Camera




- Remove the two screws holding the internal camera in place.

Step 4



- Carefully remove the tape of the ribbon cables attached to the camera.

Step 5



- Using a plastic opening tool, lift open the tab that holds the connection between the camera and motherboard in place. The ribbon cable will become detached.

Step 6



- Finally, detach the camera lenses from the cover by gently pulling them away from the case.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 05:49:52 PM.